GEA Mission

The Global Electronics Association promotes industry growth and strengthens supply chain resilience.

About IPC Standards by Global Electronics Association

IPC standards and publications by Global Electronics Association are designed to serve the public interest through eliminating misunderstandings between manufacturers and purchasers, facilitating interchangeability and improvement of products, and assisting the purchaser in selecting and obtaining with minimum delay the proper product for their particular need. Existence of such standards and publications shall not in any respect preclude any entity from manufacturing or selling products not conforming to such standards and publications, nor shall the existence of such standards and publications preclude their voluntary use.

IPC standards and publications by Global Electronics Association are approved by committees without regard to whether the standards or publications may involve patents on articles, materials or processes. By such action, Global Electronics Association does not assume any liability to any patent owner, nor does Global Electronics Association assume any obligation whatsoever to parties adopting a standard or publication. Users are wholly responsible for protecting themselves against all claims of liabilities for patent infringement.

Global Electronics Association Position Statement on Specification Revision Change

The use and implementation of IPC standards and publications by Global Electronics Association are voluntary and part of a relationship entered into by customer and supplier. When a standard or publication is revised or amended, the use of the latest revision or amendment as part of an existing relationship is not automatic unless required by the contract. Global Electronics Association recommends the use of the latest revision or amendment.

Standards Improvement Recommendations

Global Electronics Association welcomes comments for improvements to any standard in its library. All comments will be provided to the appropriate committee.

If a change to technical content is requested, data to support the request is recommended. Technical comments to include new technologies or make changes to published requirements should be accompanied by technical data to support the request. This information will be used by the committee to resolve the comment.

To submit your comments, visit the Status of Standardization page at www.electronics.org/status.

by Global Electronics Association

IPC-HERMES-9852
Version 1.7



IPC-HERMES-9852

The Global Standard for Machine-to-Machine Communication in SMT Assembly

If a conflict occurs between the English language and translated versions of this document, the English version will take precedence.

Developed by The Hermes Standard Initiative and the IPC-HERMES-9852 Standard Task Group (2-17b) of the Electronic Product Data Description Committee (2-10) of IPC

Users of this publication are encouraged to participate in the development of future revisions.

Contact:

Global Electronics Association
3000 Lakeside Drive, Suite 105N
Bannockburn, Illinois
60015-1249
Tel 847 615.7100
Fax 847 615.7105

Supersedes:
IPC-HERMES-9852,
Version 1.6 – May 2024
IPC-HERMES-9852,
Version 1.5 – November 2022
IPC-HERMES-9852,
Version 1.4 – February 2022
IPC-HERMES-9852,
Version 1.3 – May 2021
IPC-HERMES-9852,
Version 1.2 – June 2019
IPC-HERMES-9852,
Version 1.1 – April 2018
IPC-HERMES-9852,
Version 1.0.1 – November 2017
IPC-HERMES-9852,
Version 1.0 – March 2017

Table of Contents

1 SCOPE ... 1
2 TECHNICAL CONCEPT ... 1
2.1 Prerequisites ... 1
2.2 Board IDs ... 1
2.3 Machine-to-Machine Communication (Horizontal Channel) ... 2
2.3.1 Topology ... 2
2.3.2 Connecting, Handshake and Detection of Connection Loss ... 3
2.3.3 Normal Operation ... 5
2.3.4 Transport Error Handling ... 5
2.3.5 Handling of BoardForecast ... 10
2.3.6 Protocol States and Protocol Error Handling ... 13
2.3.7 Handling of Attribute 'Route' ... 14
2.3.8 Handling of Attribute 'Action' ... 14
2.4 Remote Configuration ... 14
2.4.1 Topology ... 14
2.4.2 Remote Configuration ... 14
2.5 Communication with Supervisory System (Vertical Channel) ... 14
2.5.1 Topology ... 14
2.5.2 Connecting, Handshake and Detection of Connection Loss ... 15
2.5.3 Protocol States and Protocol Error Handling ... 16
2.6 Hermes Side Channel ... 17
3 MESSAGE DEFINITION ... 17
3.1 Message Format ... 17
3.2 Root Element ... 18
3.3 CheckAlive ... 18
3.4 ServiceDescription ... 18
3.5 Notification ... 19
3.6 BoardAvailable ... 20
3.7 RevokeBoardAvailable ... 21
3.8 MachineReady ... 22
3.9 RevokeMachineReady ... 22
3.10 StartTransport ... 22
3.11 StopTransport ... 23
3.12 TransportFinished ... 23
3.13 SetConfiguration ... 23
3.14 GetConfiguration ... 24
3.15 CurrentConfiguration ... 24
3.16 BoardForecast ... 24
3.17 QueryBoardInfo ... 25
3.18 SendBoardInfo ... 26
3.19 SupervisoryServiceDescription ... 28
3.20 BoardArrived ... 28
3.21 BoardDeparted ... 31
3.22 QueryWorkOrderInfo ... 34
3.23 SendWorkOrderInfo ... 35
3.24 ReplyWorkOrderInfo ... 37
3.25 Command ... 37
3.26 QueryHermesCapabilities ... 38
3.27 SendHermesCapabilities ... 39
3.28 AddExtendedBoardInfo ... 40
3.29 QueryExtendedBoardInfo ... 40
3.30 SendExtendedBoardInfo ... 40
4 APPENDIX ... 40
4.1 Special Scenarios ... 40
4.1.1 Board Tracking When Board Is Torn Out From the Line ... 41
4.1.2 Board Tracking When Board Is Temporarily Removed From the Line ... 41
4.1.3 Board Tracking When Board Was Transferred without Data ... 42
4.1.4 Oven Error Loop ... 43
4.1.5 Request Pause / Confirm Pause and Resume Operation ... 43
4.1.6 Board Removal at Downstream Conveyor ... 44
4.1.7 Reversal Transportation to a Flipping Unit Located Downstream a Process Machine ... 45
4.1.8 Reversal Transportation to a Flipping Unit Located Upstream a Process Machine ... 46
4.1.9 Board Routing within a Production Line by Predefined Routes ... 47
4.1.10 Board Routing within a Production Line Towards Target Locations ... 48
4.2 Glossary / Abbreviations ... 49
4.3 References ... 49
4.4 History ... 50

Figures

Figure 1 Generation of Board IDs ... 2
Figure 2 TCP Connections in a Line ... 2

Figure 3 Upstream and Downstream from the Perspective of the Machine 2
Figure 4 Connection, Handshake and Connection Loss Detection on Horizontal Channel 3
Figure 5 Example for Connection Loss Detection with FeatureCheckAliveResponse on Horizontal Channel 4
Figure 6 Communication Sequence for Board Transport 5
Figure 7 Communication Sequence in Scenario U1a 6
Figure 8 Communication Sequence in Scenario U1b 6
Figure 9 Communication Sequence in Scenario U2 7
Figure 10 Communication Sequence in Scenario U3 8
Figure 11 Communication Sequence in Scenario D1 8
Figure 12 Communication Sequence in Scenario D2 9
Figure 13 Communication Sequence in Scenario D3 10
Figure 14 Example of Communication Sequence for BoardForecast 11
Figure 15 Example of Communication Sequence for BoardForecast with RevokeMachineReady ... 11
Figure 16 Example of Communication Sequence with Several BoardForecast 11
Figure 17 Example of Communication Sequence in Case with Error Handling 12
Figure 18 Example of Communication Sequence BoardForecast without Product Change 12
Figure 19 Hermes Interface States on Horizontal Channel 13
Figure 20 Connection, Handshake and Connection Loss Detection on Vertical Channel 15
Figure 21 Example of Connection Loss Detection with FeatureCheckAliveResponse on Vertical Channel 16
Figure 22 Hermes Interface States on Vertical Channel.. 16
Figure 23 Explanation for Top and Bottom Clearance Height..... 21
Figure 24 Line Setup with Barcode Readers and Repair Station 41
Figure 25 Line Setup with Fixed and Mobile Barcode Readers – Board Temporarily Removed from Line 41
Figure 26 Line Setup with Fixed and Mobile Barcode Readers – Board Transferred without Data.... 42
Figure 27 SMT Subline That Is Involved in Oven Error Loop 43
Figure 28 Example Subline Showing Use Case Request Pause / Confirm Pause and Resume Operation 43
Figure 29 Board Removal at Downstream Conveyor 44
Figure 30 Reversal Transportation, Downstream Flipping Unit 45
Figure 31 Reversal Transportation, Upstream Flipping Unit 46
Figure 32 Board Routing, Predefined Routes..... 47
Figure 33 Board Routing, Multiple Target Locations 48

IPC-HERMES-9852 Version 1.7
The Global Standard for Machine-to-Machine Communication in SMT Assembly

1 SCOPE

The aim of this specification is to create a state-of-the-art communication protocol for handling board transfers and associated data at surface-mount technology (SMT) production lines. Therefore, this new communication protocol has to cope with the following:

- Replace the electrical SMEMA interface as specified in IPC-SMEMA-9851
- Extend the interface to communicate:
  - Unique identifiers for the handled printed circuit boards (PCBs)
  - Equipment identifiers of the first machine noticing a PCB
  - Barcodes
  - Conveyor speed and intended board route
  - A lightweight digital twin of the product containing, e.g.,
    - Product type identifier
    - Length
    - Width
    - Thickness
    - Board state

With respect to version numbers The Hermes Standard adheres to the rules of Semantic Versioning 2.0.0 [SemVer_2.0.0]. Hints on naming:

- Wherever a feature is described by the word "**shall**" it is mandatory.
- The word "machine" is used for any equipment which can be found in a SMT production line (e.g., printers, placement machines, ovens, AOIs, transport modules, shuttles, stackers).
- The term "PCB" may also refer to carriers transporting PCBs.
- The word "Hermes" is used as abbreviation for "The Hermes Standard".
- "The Hermes Standard" and IPC-HERMES-9852 are synonyms for the standard specified in this document and might be used interchangeably.

2 TECHNICAL CONCEPT

2.1 Prerequisites This specification is based on the prerequisite that any application implementing this protocol has to provide connectivity based on Internet Protocol (IP) [IETF_RFC_791] / [IETF_RFC_2460] via Transmission Control Protocol (TCP) [IETF_RFC_793] (ISO / OSI model [ISO_7498-1] layer 3) to the adjacent machines and for communication with supervisory systems.

2.2 Board IDs Board individuals are identified by board IDs. These must be Globally Unique Identifiers (GUIDs) according to [ITU-T_REC_X.667], e.g., 123e4567-e89b-12d3-a456-426655440000. They are generated by the first machine in a consecutive row of machines implementing the Hermes protocol. The board ID is passed from machine to machine. If a machine in a line does not implement the Hermes protocol, the board ID is lost and a new one will be generated by the next machine implementing Hermes.